

## Load Cells for H2-50TH Dummy

Load Cell Model #	Load Cell Description	Calibration Fixture	Axis
<b>IF-400</b>	3-Axis Lumbar Spine Load Cell	4000-50	FX, FY, FZ
<b>IF-405</b>	6-Axis Lumbar Spine Load Cell	4050-50	FX, FY, FZ, MX, MY, MZ
<b>IF-604</b>	Uniaxial Femur Load Cell	6040-50	FZ